





Consecutive labellers

CODE	DESCRIPTION	CODE	DESCRIPTION	CODE	DESCRIPTION
01A	BLITZ BODY SIDE RIGHT	PR20B	INK ROLLER HOLDER SHAFT FOR CONSECUTIVE	P59	HOLDING STRAP
01B	BLITZ BODY SIDE LEFT	P29	PRESS. ELEMENT HOLDER SHAFT	P60	LOCKWASHER
P02	HANDLE	P30	BASE PLATE OPENER SHAFT	PR61	COMPLETE SHAFT FOR N°68 GEARS
P02B	HANDLE FOR CONSECUTIVE LAB.	P31	SPROCKET SHAFT	PR62A	NEW PAWL
P03	BASEPLATE	P32	SHAFT TO AFFIX HANDLE	PR62B	BASE FOR PR62A
P04	ROLLER FOR GUIDE	P33	HANDGRIP SHAFT	PR62E	BRASS PART
P05	PRESSURE ELEMENT HOLDER	P34	INK ROLLER HOLDER SPRING	PR63	PAWL ADVANCER
06	PLASTIC GRIPS	P35/C	CONSECUTIVE HANDGRIP SPRING	PR64	CONSECUTIVE DRUM GEAR
07	INK ROLLER	P36B	BRAKE SPRING	P65	SHAFT FOR NEW PAWL
P08	APPLICATOR ROLLER BUSHING	PR37C	PRINT CASE RIGHT SIDE	PR65	DUPLICATING GEAR
P09	APPLICATOR ROLLER	PR37D	PRINT CASE LEFT SIDE	P66	TORSION SPRING
10	FRONT PROTECTION PLATE	38	BLITZ KNOB	PR66	REPEAT DRUM
P11	DRUM ADVANCER FOR P02	PR393P	BUSH FOR CONSECUTIVE	PR67B	SIDE COVER PER PAWL
P11B	DRUM ADVANCER FOR P02B	PR40	INDICATOR	P68	SHAFT FOR GUIDE PLATE SPROCKET COVER
P12	LABEL ADJUSTMENT PLATE	PR41	GEARED WHEEL FOR STATIC BANDS	PR68	GEARS FOR CHANGING 10'S OR 100'S WHEELS
13	INK ROLLER HOLDER	PR42	PROGRESSIVE GEARED UNIT WHEEL	P69	SCREW FOR BRAKE ADJUST.
P14	GUIDE PLATE SPROCKET COVER	PR42BEC	PROGRESSIVE GEARED UNIT WHEEL 10'S POSITION	PR69	INKED ROLLER CONTROLLER
P15B	PAPER STRECHER BRAKE	PR43A	PRINT POSITIONER UNIT-CONSECUTIVE BANDS	PR70	SHAFT FOR INKED ROLLER CONTROLLER
16	BLITZ LABEL ROLL CONTAINER	PR43B	PRINT POSITIONER UNIT-STATIC BANDS	PR71	SPRING FOR INKED ROLLER CONTROLLER
17F	LABEL ROLL COVER GREY	PR44	SPACER FOR ADJUSTMENT SHAFT	PR72	RETAINING RINGS FOR PR63
P17	LABEL ADVANCING DRUM	PR45	SPACER FOR PRINT AXLE	PR72A	SELF STOPPING WASHER
PR18B	SHAFT FOR PAWL ADVANCER	PR46	ADJUSTMENT SHAFT	PR73	ADJUSTMENT SCREW FOR PAWL
P19	SCREW	PR47	COMPLETE PRINT AXLE	PR78	BAND SEPARATOR
20	BLITZ LABEL ROLL HOLDER UNDER COVER	P40AB	PRINT CASE HOLDING SHAFT	PR81A	BRASS RING
21	SHAFT FOR PART N. 20	PR50	ALLEN SCREW	PR82	SHAFT 3X5.2 FOR RED LOCK
22	SPRING FOR PART N. 20	P52C	PIN FOR WHEELS CONSECUTIVE	PR83	SHAFT 3X7.3 FOR SECURITY LEVER
P22	PRESS. L. HOLDER SCREW	P53	ADJUST. KNOB SCREW	PR84	RED LOCK
P24	RETAINING RINGS FOR P27+PR18B	P54	PRINT HEAD SCREW	PR85	SECURITY LEVER
P25	GUIDE PLATE SCREW	PR55A	CONSECUTIVE BAND	PR87	SPRING FOR NEW PAWL
PR25	RETAINING RINGS FOR PR62A	PR55B	STATIC BAND	PR88	SHAFT 2X6.8 FOR NEW PAWL
P26	SCREW TO HOLD THE PRINT UNIT	P57	LABEL ROLL		
P27	BRAKE SHAFT	P58	MOD. LABEL		